

Optimizing rheology for paint and coating applications




Torsten Remmler, Malvern Instruments GmbH

Outline

- › Typical Process Conditions for Paints and Coatings
- › How to measure the Viscosity?
- › Impact of Particle Properties: Size, Volume, Polydispersity
- › Storage Stability
- › Summary

Shear Flow Properties: Overview of Basic Terms

- › Temperature
- › Pressure
- › Shear Rate (Speed)
- › Shear Stress (Force)
- › Time



Dynamic Shear Viscosity*:

$$\eta (T, p, t, \dot{\gamma}) = \frac{\sigma}{\dot{\gamma}}$$

Unit: $[\eta] = 1 \text{ Pas}$


$$\dot{\gamma} = \frac{d\gamma}{dt}$$

Shear rate [1/s]

$$\sigma = \frac{F_{\text{tan}}}{A}$$

Shear stress [Pa=N/m²]


Typical Shear Rate Ranges for Paints and Coatings



How to calculate the Shear Rates?




Blade Coating,
Brushing




$$\dot{\gamma} = \frac{v}{h}$$

Slot Die Coating



$$\dot{\gamma}_{\text{app}} = \frac{6 \cdot Q}{b h^2}$$


Spraying



$$\dot{\gamma}_{\text{app}} = \frac{4 \cdot Q}{\pi R^3}$$

Q = Volume Flux, R = Die Radius, L = Die Length, b = Slot Width
 h = Slot Height, v = Velocity, h = Wet Layer Thickness



Principle of Operation: Rotational Rheometer



kinexus

Principle of Operation: Capillary Rheometer

Given quantity: piston speed \Rightarrow wall shear rate
 Measured quantity: pressure drop \Rightarrow wall shear stress




Full pressure drop
 =
 Entrance pressure drop
 +
 Shear pressure drop



Malvern RH2000

www.malvern.com

Interpretation of Shear Viscosity Curves of Coatings





⇒ Low Shear Data needed for Stability Analysis

⇒ High Shear Limit: Stress must not drop with increasing Shear Rate

Optimizing Rheology of Coatings:

1. Impact of Adding Coarse or Fine Particles




- Small particles increase the low shear viscosity, as they have more surface area which gives more electrostatic and inter-particle forces.
- Note that the viscosity is almost independent of particle size at higher shear rates, as here hydrodynamic forces dominate

Optimizing Rheology for Coatings:


2. Impact of Particle Loading

› Changing the volume fraction of the particles....




Krieger-Dougherty:

$$\frac{\eta}{\eta_{medium}} = \left(1 - \frac{\phi}{\phi_m}\right)^{-[\eta]\phi_m}$$



Norman J. Wagner, J. B. (2009). Shear thickening in colloidal dispersions. *Physics Today*, 27-32.

Example: Shear Thickening of a Spray Coating






⇒ Shear Thickening at High Shear Rates: Critical for Spray Process

⇒ Strong Shear Thinning at Low Shear Rates: Defines the Structure Build-Up after Spraying

Optimizing Rheology for Coatings:


3. Impact of Polydispersity

- ▶ We keep the volume fraction (ϕ) constant
- ▶ But changing polydispersity...



- ▶ What happens to the viscosity?

Impact of Polydispersity on Flow Behaviour



- ▶ If you want to increase the solid content of the sample but keep the viscosity the same, increase the particle size distribution (polydispersity) as well.
- ▶ Conversely, narrow the particle size distribution to increase the viscosity.

Further Factors affecting Coating Rheology

Laser Diffraction




Spray Particle Analyzer




Light Scattering
Size and Zeta




Volume fraction ϕ



Particle size




Particle size distribution




Digital Microscopy




Electrostatic interactions



Steric Hindrance



Particle shape



Dry



Wet




Storage Stability: Importance of Zero Shear Viscosity

Shear Stress by Gravity:

$$\begin{aligned}\sigma &= \frac{F}{A} = \frac{m \cdot g}{A} = \frac{(\rho_1 - \rho_2) \cdot V \cdot g}{A} \\ &= \frac{(\rho_1 - \rho_2) \cdot \frac{4}{3} \cdot \pi \cdot r^3 \cdot g}{4 \cdot \pi \cdot r^2} \\ &= \frac{(\rho_1 - \rho_2) \cdot r \cdot g}{3}\end{aligned}$$

Settling Speed:

$$v = \frac{2}{9} \cdot \frac{(\rho_1 - \rho_2) \cdot r^2 g}{\eta}$$



v = settling speed, r = particle radius, ρ_1 = density of the particle
 ρ_2 = density of the fluid, g = gravitational acceleration
 η = dynamic shear viscosity

Summary

- Rotational and Capillary Rheometry cover the typical Processing Conditions for Paints and Coatings
- Shear Viscosity Function related to Particle Properties (Size, Polydispersity, Volume)
- Storage Stability: Importance of Zero Shear Viscosity

Any Questions?